

AQUELIX

Chrome Waterfall Basin Faucet

Model AQX-0629-16 | Installation Guide

Installation sequence

1. Confirm basin hole pattern, deck thickness, spout reach and handle clearance.
2. Flush supply lines and protect the visible finish during installation.
3. Install the faucet or rough-in body square to the basin centerline.
4. Connect supply hoses without kinks or torsion.
5. Fit the aerator after flushing debris from the outlet.
6. Check leakage, flow, splash and drain clearance.

Before installation

Use the signed model drawing and local plumbing requirements. Installation must be completed by a qualified person. Stop and request clarification if connection type, pressure, wall depth, hole size or included components differ from the approved order.

Care and handover

Use a soft cloth and neutral cleaner. Do not use abrasive pads, strong acid, bleach or aggressive descalers on decorative finishes. Record the model and batch, keep the spare-parts list, and provide the maintenance team with the approved cartridge, aerator, hose or filter references.