

AQUELIX

High-Pressure Hand Shower

Model AQX-0629-47 | Installation Guide

Installation sequence

1. Confirm G1/2 connection, hose reach and holder position.
2. Flush the shower line before attaching the product.
3. Fit sealing washer; hand-tighten, then use only the approved final tightening method.
4. Install any flow regulator in the specified orientation.
5. Run each spray mode and check leakage at operating pressure.
6. Provide filter replacement and cleaning instructions to the end user.

Before installation

Use the signed model drawing and local plumbing requirements. Installation must be completed by a qualified person. Stop and request clarification if connection type, pressure, wall depth, hole size or included components differ from the approved order.

Care and handover

Use a soft cloth and neutral cleaner. Do not use abrasive pads, strong acid, bleach or aggressive descalers on decorative finishes. Record the model and batch, keep the spare-parts list, and provide the maintenance team with the approved cartridge, aerator, hose or filter references.