

AQUELIX

Square Concealed Shower System

Model AQX-0629-55 | Installation Guide

Installation sequence

1. Pressure-test and flush concealed pipework before closing the wall.
2. Confirm inlet centers, finished-wall depth and outlet locations from the approved drawing.
3. Install the rough-in body level and provide service access where specified.
4. Connect overhead and hand-shower outlets; do not mix inlet and outlet ports.
5. Fit trim only after wall finishes are complete.
6. Test temperature, diverter operation, flow and leakage on every outlet.

Before installation

Use the signed model drawing and local plumbing requirements. Installation must be completed by a qualified person. Stop and request clarification if connection type, pressure, wall depth, hole size or included components differ from the approved order.

Care and handover

Use a soft cloth and neutral cleaner. Do not use abrasive pads, strong acid, bleach or aggressive descalers on decorative finishes. Record the model and batch, keep the spare-parts list, and provide the maintenance team with the approved cartridge, aerator, hose or filter references.